
PLC LIGHTING

14861, 14863, 14864

INSTALLATION INSTRUCTIONS:



- 1. Ensure mains supply is switched off.
- 2. Fit cross bar(1) onto mounting surface with self-tapping screws(2).
- 3. Make the wiring connections: Using wire connectors (3), connect the house white wire(s) to the fixture white(or ribbed) lead(s); connect the house black(or red) wire to the fixture black (or smooth)lead(s). Make sure that there are no exposed wires or stands, and that the connections are secured.
- 4. Fit wall plate (4) onto crossbar with screws & nuts (5)
- 5. Fit bulbs (6) firmly into lampholders.
- 6. Fix the glass shade (7) onto metal tube (8).
- 7. Fit metal frame onto glass shade securing with metal washer & decorative parts & final(10).

WARNING:

- Electricity supply required 110-120v 60 htz alternating current.
- Use only the correct light bulbs as stipulated on the luminaries .
- Disconnect the power and allow fitting cool down before cleaning or changing bulb(s).
- If any malfunction occurs, switch of mains and contact a qualified electrician.
- Do not modify this unit in any manner.